
# LE307-400




#### **Product Information:**



400 x200 x 51mm	
Steel + Aluminum + PMMA+ ABS	
Matt black/Matt white	
SMD 2835 LED, CRI≥80, SDCM<6	
25°C - Indoors	
-20°C to 45°C - Indoors	
$\coprod$	
IP20	
3.7V 4500mAh	
Wall Mounted	
Remote controller, Mounting panel, 1.5m cable USB Type-C,	
Expansion Pipes(2pcs), Screws(2pcs)	
Charging: RED indicator	
Fully charged: GREEN indicator	
LE307-400	
4	
190	
DC5V 1A	
6	
9 (brightest)	
60+60	
3000-4000-6500	

### **Product Size:**



### Function:

This rocker switch is used to turn the battery on/off.

In ON mode, the light can be turned on/off.

In OFF mode, the light cannot be turned on.

The light must be used in conjunction with the remote control


#### Match the remote control:

Turn the rocker switch on the light from "OFF" to "ON", press and hold the button remote control for 5 seconds, after the light flashes twice, the matching is successful.



### Cancel remote control:

Turn the rocker switch on the light from "OFF" to "ON", press and hold the button remote control for 5 seconds, after the light flashes once, cancel the remote control.



#### Remote control function:

2



: light ON/OFF;


: CCT 6500K/3000K/4000K;

: Dim+/-: 100%-10% or 10%-100%;

: Set to automatically shut down after 15 minutes/ 30 minutes/ 60 minutes.

### Installation Information:

## Wall Mounted



- Drill two holes (Φ6) on the wall, and the distance between two holes is 90mm, put the expansion screws into the holes.
- 2. Fix the mounting panel with screws.
- 3. Fix lamp on the mounting panel.