


INSTRUCTION MANUAL

L1020-B



LAMP ROTATING FUNCTION



Flexible angle for arm and light cover caters for all needs.
The lampshade can be rotating angles and the connecting rod can be adjusted up to down

OPERATING INSTRUCTION

1. This appliance is operated on low voltage power supply (DC24V), please connect with the correct adaptor while using.
2. Connect the adaptor to the DC socket on the machine and connect the other end to the home power outlet.
3. Power On/Off Press once and this appliance start
Touch Control : operate.Press again to shut it down.
4. Brightness Press this key can adjust the brightness.
Touch Control: Long press can adjust as variable control.
5. Light Source Press this key can adjust the light source
Select (color temperature):
Touch Control: White light <-> Natural light (mix of white & day light) <-> Warm Day light
6. This appliance have function memory if power supply is connected.
The workin status will resume as last used when switch on a in.
7. Before using the magnifier, please open the magnifier cover first. Then place the object/document under the magnifier on a flat surface.The suggested distance between the magnifier and the object is ~15cm.

SPECIFICATION

Technical Product Specification			
MODEL	OUTPUT POWER	ADAPTOR VOLTAGE	COLOR TEMP
L1020-B	8W	DC24V,375mA	2700K~6500K

LED LAMP THE PREFERRED CHOICE

Eye Care-NO UV Rays. Reduces fatigue, which sometimes may lead to tearing from eyes and headaches.

Anti-Flicker-The LED lamp is made to be flicker-free,thus reducing eye disturbance while reading. Glare Reduction-Reduces direct or reflective glare on reading materials. Provides optimal lighting, thus makes reading, working and playing more enjoyable and comfortable.

Longer Bulb Lifespan- With LED technology, LED bulb is made to last longer than normal light bulb or fluorescent light tube.

CAUTION



The desk lamp is only for indoor using.



Please do not use the lamp in damp environment.



Please don't put in the soft, flammable places.



Do not place lamp near the hot objects or in direct sunlight.



Do not use solvents, abrasives, or aerosol cleaners to clean the lamp;discolor may occurs.



If not using the lamp for an extended period of time,unplug the power supply plug from the outlet.



Do not remove the cover or modify the lamp in any way.High voltages can cause fire or electric shocks.



Output wire in use process can not be knotted, tied into a group, etc, must let the wire naturally stretch.



Please pull out the plug immediately when in the use of abnormal(such as the smoke or odors.)



Please do not touch the plug with a wet hand.

TROUBLE SHOOTING

- 1.If the lamp does not turn on, please check the following steps:
 - a.Make sure the power supply plug is securely plugged into the wall outlet or the power supply.
 - b.Make sure the power supply connector & DC socket are connected.
- 2.If the lamp does not turn on after you perform the above steps, send it to the authorized service centre for examination and repair.

Do not attempt to take apart or modify the lamp in any way. Doing so could cause the risk of serious injury or death from electric shock or fire, and it will void your warranty.