



IP65 Ceiling Light

Specifications


Model	Size (A* Bmm)	Power (W)	Flux (LM)	FLUX(LM) Module	Voltage (V)	PF	CRI	Beam Angle	Energy Class	Color Temperature(K)	Lifespan (hour)	Protection Rate	Working Temperature(°C)
B1760-18W	Φ250* 48	18	1350	1880	185-265	≥ 0,8	80	120°	F	3000K/4000K/6500K	25000	IP65	-20 °C ~ 40 °C
B1760-30W	Φ350* 48	30	2340	3255	185-265	≥ 0,9	80	120°	F	3000K/4000K/6500K	25000	IP65	-20 °C ~ 40 °C



Function Options



Standard



CCT Change by Dip Switch

Notes



- Before using or installing the product, please read the instructions and follow the safety rules. Installation should be carried out by a qualified professional or company.
- Before using check the product and ensure that it is not damaged in any way; if it is, do not use it. Before any installation ensure that the main electrical supply is disconnected. If the product is damaged, do not attempt to repair or disassemble it. The light source contained in this luminaire shall only be replaced by the manufacturer or his service agent or a similar qualified person.
- Failure to follow these instructions can cause damage to health and property. The warranty is void if the product is damaged or installed incorrectly.

WARNING



- * Power should be cut off before installation, maintenance or inspection.
- * Please install and use the light strictly according to the instruction.
- * Do not disassemble or remold the product at will to avoid accident of electric shock or light falling.
- * Working out of temp. range -20°C ~ +40°C will shorten the lifetime of luminaires.

IP65 Ceiling Light

Installation

